

Stanislawski Double Eagle

Trigger: adjustable for height by loosening flat head cap screw and sliding trigger up and down. You will note that if the trigger is not centered properly, the release will be difficult to cock. Should you find this to be the case, loosen the trigger and try to center it such that sides A and B do not touch the case (black part) at any time during the cocking sequence.

