



IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Three Finger X-Large



Extension Set High




Extension Set Mid




Extension Set Low

IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Three Finger Large



Extension Set High




Extension Set Mid




Extension Set Low

IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Three Finger Medium



Extension Set High




Extension Set Mid




Extension Set Low

IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Three Finger Small



Extension Set High




Extension Set Mid




Extension Set Low

IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Four Finger X-Large



Extension Set High




Extension Set Mid




Extension Set Low

IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Four Finger Large



Extension Set High






Extension Set Mid



Extension Set Low


IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.

PerfeX_{THUMB} Four Finger Medium




IMPORTANT: Print this document without any scaling or fit to print options selected on your printer.


PerfeX_{THUMB} Four Finger Small



Extension Set High



Extension Set Mid



Extension Set Low